

Installing a Wood Panel Fence

Tools & Materials

- □ Posts
- □ Post Hole Digger
- □ Paint or Outdoor Stain
- □ Steel Tape
- □ Nails
- □ Hand Saw
- □ Hammer
- □ Level
- □ Ready-Mix Concrete

Installing the Fence Posts □ As a rule, you should set fence posts about 1.8m to 2.0m apart.

Set the corner or end post first. Then stretch a line from each corner or end post to align all the posts in between.

Drive a stake every 1.8m to 2.0m at the exact position where the post hole is to be dug.

Take time to measure and position the posts accurately. The appearance and the structural strength of your fence depends a great deal on the positioning and depth of the fence posts. Depth 600mm minimum.

It is essential that all fence panel tops are level.

Try to keep the bottom rail of any fence at least 50mm above the ground.

This helps eliminate the problem of decay and makes it easier to trim grass around the base of the fence.

Take the appropriate measurements as shown, then visit your Lifestyle fence DIY panel stockist or call us. It's that simple !

